



H1 ELASTIC SUSPENSION (4x2 OPTION)  
 H1 OIL OPSTICK TRANSMISSION  
 H2 CONNECTION SHIFTS SOLENOIDES  
 SCALE: 1:8  
 FOR MORE DETAILS SEE DRAWING 35914-8

In every dimension and weight of the drawing shall be used the metric system and the units shall be in millimeters and kilograms.	SYMBOLS, DIMENSIONS AND WEIGHTS SHALL BE USED IN MILLIMETERS AND KILOGRAMS	
	ENGINE INSTALLATION 09 M1 H1 / M1514 DC	
<b>VOLVO PENTA</b>		INSTALLATION DRAWING 35214-31
35214-31	05	10